

CERTIFICATE OF CALIBRATION

ISSUED BY: **CALIBRATION MAINTENANCE & REPAIR LTD**



0654

DATE OF ISSUE: 16 January 2025

CERTIFICATE NUMBER: **1174284**



Unit 5 Octavian Way
Team Valley Trading Estate
Gateshead
NE11 0HZ

Tel: +44 (0)191 4875951

Page 1 of 3

Approved Signatory

Electronically Authorised Document

P K CLARK J FRYER
 R J WADE M FOY
 M A FROST
 M S PARDOE

CUSTOMER

DJB LABCARE LTD
UNIT 12 HOWARD WAY
CROMWELL BUSINESS CENTRE
NEWPORT PAGNELL
BUCKINGHAMSHIRE
MK16 9QS
UNITED KINGDOM

MANUFACTURER

DESCRIPTION

MODEL

SERIAL No.

IDENT No.

DATE RECEIVED

DATE OF CALIBRATION

ORDER No.

STANDARD

TACHOMETER OPTICAL

AT-6

12078389

UNKNOWN

8 JANUARY 2025

16 JANUARY 2025

NS24036

INSTRUMENT CONDITION

Adjustments Made
Repairs Made

No
No

ENVIRONMENT

The instrument was placed in the Laboratory environment for a minimum period of 4 hours prior to calibration.

The ambient conditions were: 18 to 23°C and 45 %rh ± 15 %rh.

STABILITY

The results contained in this Certificate refer to the measurements made at the time of test and not to the instrument's ability to maintain calibration.

PROCEDURE

Measurements were performed in accordance with the in house Laboratory procedure No.1053

The reported expanded uncertainty is based on a standard uncertainty multiplied by a coverage factor $k = 2$, providing a coverage probability of approximately 95 %. The uncertainty evaluation has been carried out in accordance with UKAS requirements.

CERTIFICATE OF CALIBRATION

ISSUED BY: **CALIBRATION MAINTENANCE & REPAIR LTD**

UKAS ACCREDITED CALIBRATION LABORATORY No. 0654



CERTIFICATE NUMBER

1174284

Page 2 of 3

Calibration Equipment Used:

Cert Number	Ident Number	Model	Serial Number	Test Equipment Calibration Due
1168575IH	143	33220A	MY44025316	3 Oct 2025
1149606IH	574	A002206.G1	13431078	18 Sep 2026

Notes:

Results relate only to the items calibrated.

CERTIFICATE OF CALIBRATION

ISSUED BY: **CALIBRATION MAINTENANCE & REPAIR LTD**

UKAS ACCREDITED CALIBRATION LABORATORY No. 0654



CERTIFICATE NUMBER

1174284

RESULT SHEET 1053-NC-UKAS : STANDARD AT-6 OPTICAL TACHOMETER

AS FOUND

BATTERY REPLACED: NO

The Revolution Per Minute (RPM) was simulated using a precision Frequency Generator with an attached optical light source.

RPM

Range	Simulated	Indicated	Units	Indicated Deviation	Measurement Uncertainty ±
2 to 99999RPM	600.000	600.0	RPM	0.000	0.064
	1000.00	1000	RPM	0.00	0.58
	2500.00	2500	RPM	0.00	0.58
	5000.00	5000	RPM	0.00	0.58
	7499.99	7500	RPM	0.01	0.58
	9999.80	10000	RPM	0.20	0.58
	14999.44	15000	RPM	0.56	0.58
	19999.16	20000	RPM	0.84	0.58
	24998.76	25000	RPM	1.24	0.58
	29998.43	30000	RPM	1.57	0.58

Manufacturer stated Accuracy: $\pm(0.05\%+1 \text{ digit})$

COMMENTS:

TEST ENGINEER: J Stobo

DATE: 16th January 2025